## **GLUING THE SHAFT**

## Attaching the parts together

We recommend using slow curing two compound epoxy glue for a reliable joint.

- **A.** When the shaft is prepared to fit the greenland paddle split system it is important to close / seal all open wooden surfaces inside in the joint with liquid epoxy to prevent water absorption into the wood.
- **B.** Spread the epoxy glue smoothly into the gluing surface
- **C.** Push the greenland paddle split system firmly on it's place in the paddle shaft.

